

EIZO Releases eClient® 630L-N and 630LT-GR-N Single Unit LCD-WBTs feature Windows CE.NET 4.1 OS



Matto, Japan, May 9, 2003 – Eizo Nanao Corporation introduced its latest all-in-one 15-inch LCD and WBT (Windows-based Terminal) products, the eClient 630L-N and the touch panel operated eClient 630LT-GR-N. These new models are based on the already available eClient 630L and 630LT-GR, but bring the latest technology to server-based computing with the inclusion of the new Microsoft® Windows® CE.NET 4.1 operating system.

The CE .NET 4.1 OS allows for a number of improved performance features. By connecting to the new Windows ServerTM 2003 via RDP (Remote Desktop Protocol) 5.1, the eClients display 16-bit (65,536) color and provide support for peripherals connected to the COM (serial) port as well as local drive mapping. The new OS supports VPN (Virtual Private Network) client software for remote access to the terminal server and expands support for USB peripherals from the keyboard and mouse to include other peripherals such as storage devices and printers. An Internet Explorer 5.5-level browser is also installed. For the eClient 630L and 630LT-GR, EIZO offers an upgrade kit and license pack from CE 2.12 to CE .NET 4.1.

eClient 630L-N and 630LT-GR-N Features

Dual USB ports, one parallel port and one serial port (RS-232C) are included for connection with various peripherals. There is also a PCMCIA Type-II slot for LAN/WAN connectivity and dial-up support. Smooth network communications with the terminal server are assured through a 10/100BASE-TX Ethernet connector. For multimedia applications, two 1 watt speakers are built into the front bezel.

The eClients provide extremely fast, powerful operation with a 300 MHz CPU, 100 MHz frontside bus, 32 MB of flash memory, and 64 MB of ram. The 15-inch digital LCD panel offers a resolution of 1024×768 , contrast ratio of 450:1, and brightness levels of 300 cd/m^2 for the eClient 630L-N and 240 cd/m^2 for the eClient 630LT-GR-N.

The eClient 630LT-GR-N has a touch life of over one million touches, optical clarity of 79%, and an initial touch down speed of 14 ms. The analog resistive type panel accepts touch input from both a finger and a stylus pen.

For simple management of the eClient 630L-N, 630LT-GR-N, and other eClient models, EIZO offers its Network Administrator 2.0 software. Network Administrator can be used to configure and update client settings, specify or change client IP addresses, and update firmware. A scheduling function enables system administrators to set the date and time for turning eClient terminals on and off, configuration updates, and maintenance of terminals, individually or in groups. A free



90-day trial version is available for download from eclient.eizo.co.jp.

The eClient 630L-N and 630LT-GR-N keep energy costs low by consuming only 45 watts of power during normal operation and less than 5 in power save mode for compliance with EPA ENERGY STAR® Program requirements.

Availability

The eClient 630L-N and 630LT-GR-N, eClient 630L/630LT-GR Upgrade Kit, and Network Administrator Version 2.0 are now on sale worldwide through EIZO's network of international distributors. The cabinet comes in a choice of gray or black.

About EIZO

Eizo Nanao Corporation is a leading global manufacturer of high-end visual display products with a wide range of LCD, CRT, and PDP monitors, and Windows-Based Terminals. The image quality, long-term reliability, and innovative features of EIZO monitors and WBTs make them the products of choice in many financial trading rooms, hospitals, back offices, and design studios throughout the world. EIZO is based in Japan and represented in over thirty countries by a network of exclusive distributors.

For more information, please contact: Eizo Nanao Corporation

153 Shimokashiwano Matto, Ishikawa 924-8566

Japan

Phone: +81 76 277-6792 Fax: +81 76 277-6793 http://eclient.eizo.co.jp/

###

All product names are trademarks or registered trademarks of their respective companies. eClient, Eizo, and Nanao are registered trademarks of Eizo Nanao Corporation.